

Roboty frezowania i wyrównania na całej szerokości jezdni i zatok

Kolumny 1, 2, 3, 4 oznaczają numery warstw liczone od góry.

Lokalizacja		Powierzchnia frezowania	O b j ę t o ś ć						Pole nawierzchni	Pole tworzyw (rusztów)
			frezowania	1	2	3	4	wyrównania		
km	m	m ²	m ³	m ³	m ³	m ³	m ³	m ³	m ²	m ²
0	0,00									
		92,500	4,400	6,875				1,150	137,50	
0	25,00									
		5,000	0,055	2,000				1,160	40,00	
0	35,00									
		3,000	0,045	2,000				2,000	40,00	
0	45,00									
		0,000	0,000	2,000				3,750	40,00	
0	55,00									
		0,972	0,002	1,875				2,780	37,50	
0	65,00									
		10,719	0,236	2,275				0,670	45,50	
0	78,00									
Sumy:		112,19	4,74	17,02				11,50	340,50	